



PH. 633-3070  
P.O. BOX 4391  
WHITEHORSE, YUKON

# Field Report

Started *Mar. 18*.....19*85*

Completed *Mar. 25*.....19*85*

NAME AND ADDRESS OF CLIENT	DESCRIPTION OF WORK	LOCATION OF WORK
<i>IBEX Society</i>	<i>W/W</i>	<i>Mi. 962</i>
<i>Box 4765</i>		<i>Alaska Hwy</i>
<i>Whitehorse Yukon</i>	<i>7000' VIA ANG</i>	

FORMATION LOG			DESCRIPTION OF WORK	TIME			
FROM	TO	FORMATION		DATE	FROM	TO	HOURS
			MOVE				
			Load start equipment fix ties	<i>Mar. 18</i>	<i>7:00</i>	<i>11:00</i>	<i>4</i>
			Travel	<i>Mar. 21</i>	<i>8:00</i>	<i>9:00</i>	<i>1</i>
			move on set up	<i>"</i>	<i>9:00</i>	<i>10:00</i>	<i>1</i>
<i>0'</i>	<i>22'</i>	<i>clay silt</i>		<i>"</i>	<i>10:00</i>	<i>6:00</i>	<i>8</i>
<i>22'</i>	<i>26'</i>	<i>fine silty sand Br</i>					
<i>26'</i>	<i>144'</i>	<i>B.B.</i>					
			Travel	<i>"</i>	<i>6:00</i>	<i>7:00</i>	<i>1</i>
			Travel	<i>Mar. 25</i>	<i>10:00</i>	<i>11:00</i>	<i>1</i>
			start Equipment	<i>"</i>	<i>11:00</i>	<i>12:00</i>	<i>1</i>
<i>144'</i>	<i>224'</i>	<i>BB</i>	water at 210' & 223'	<i>"</i>	<i>12:00</i>	<i>4:30</i>	<i>4.5</i>
			Develop	<i>"</i>	<i>4:30</i>	<i>6:00</i>	<i>1.5</i>
			move off travel to shop	<i>"</i>	<i>6:00</i>	<i>8:00</i>	<i>2</i>

Rcrod. of Casing & Pipe

Size	Type	Size	Type
<i>6"</i>			
Feet	Inch	Feet	Inch
<i>29</i>			

Remarks:

*1 - 5 7/8" bit*  
*1 - 5 1/2" Hammer bit*  
*50 GPM*  
*1 - drive shoe.*

Static Level	Total Rig Time	hrs.
Ground Level	Total Standby	hrs.
Top Of Casing	Drilling Mud	sacks

SIGNATURES

MIDNIGHT SUN.....

CLIENT.....

TITLE.....

TITLE.....